



#### THE EFM® 5 YEAR WARRANTY:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

EFM® warrants that its products are free from defects in materials or workmanship for up to 5 years from the date of purchase. EFM® will repair or replace any product which is defective in materials or workmanship at no charge to the customer (for parts or labour). The customer is responsible for any transportation costs.

This warranty only applies to EFM® products purchased by you, and does not extend to or cover damage caused by the incorrect use or installation of the EFM® product, through your modification of the EFM® product, cosmetic damage, general wear and tear, or damage caused by accident. This warranty does not apply to any consequential loss or damages which may be incurred through your use of the EFM® product, including but not limited to damage of any nature caused to any products used in conjunction with the EFM® product.

To claim under the warranty, you need to return the faulty EFM® product to the place of purchase (at your expense) with a valid proof of purchase. If you are not able to return the product to the place of purchase, you can contact:

**EFM Customer Service Department**  
**PO BOX 684, Belmont WA 6104**  
**P: 1300 069 336 (1300 0 MYEFM)**  
**E: [info@myefm.com](mailto:info@myefm.com)**

**Important:** For the avoidance of any doubt, this 5 Year Warranty applies to your purchased EFM® product only, and not to any device to which the EFM® product is affixed or used in conjunction with. Whilst we stand by our products, EFM® will not be liable for any damages of any nature caused to any such device from incorrect use of the product.

For more information visit [myefm.com](http://myefm.com).



#### 15W DUAL WIRELESS LEATHER CHARGE PAD USER'S MANUAL



#### PACK CONTENTS:

- 1 x EFM® 15W Dual Leather Wireless Charge Pad
- 1 x Warranty Details/Instruction Manual
- 1 x 42W Wall charger with 1.5M Type-C cable.

#### TECHNICAL SPECIFICATIONS:

Parameter	Value
Input	12V/3A
Output	15W / 10W / 7.5W / 5W
Dimensions	174mm*82mm*13mm

#### LED STATUS INDICATOR:

Colour	Status
Blue LED:	Standby; ready to charge
Blue LED (flashing)	Device charging
Red LED	Device fully charged for Samsung. For iPhone, will keep blue flashing.
Red LED (flashing)	Device not aligned correctly on charger/ Foreign object detected obstructing wireless coils.


#### CAUTION:

1. Please read the instruction manual before using this product.
2. Do not modify, repair or dismantle the wireless charge pad. Doing so may result in fire, electric shocks or a complete breakdown of the product all of which are not covered under warranty.
3. Do not use any diluent or volatile liquids to clean the product surface

1. Do not use the product in a hazardous location.
2. The product should be kept in a dry and ventilated environment, do not store in an area of high humidity and/or high temperature

#### CONNECT THE WIRELESS CHARGE PAD:

- Connect the supplied Type C cable to the designated port on your EFM® 15W Dual Leather Wireless Charge Pad.



- Plug the USB-C end of the adapter into the USB Type-C input port on the charge pad. Then plug the adapter into a power source.
- Ensure that the charge pad is positioned correctly with the leather charge platform facing upwards. (Charge platform identified by the embossed **qi** logo)
- \*Place your Qi-Supported mobile device on the charging area. Active charging area is around the Qi Symbols located at both ends of the Leather Charge Pad.
- **qi** logo positions are the best charging area.
- Check that the charge pad's LED status indicator lights up on placement of your device.

**\*Please Note:** The proper placement of your mobile device onto the charge pad will depend entirely upon the location of the wireless charging coil within your mobile device.

#### MOBILE DEVICES WITH CASES:

Wireless charging is designed to work on cases up to 3mm in depth. EFM cannot guarantee that your device will charge if you have attached a case thicker than 3mm on to your mobile device.

Please ensure that you remove any cases or covers before placing your mobile device on the wireless charge pad as they may reduce the charging efficiency.

#### PLEASE NOTE:

For optimal charge rates and more efficient charge speeds please use the included bonus 42W wall charger with 1.5M type-c cable.

#### WARNING:

Do not use unsupported devices on the wireless charge pad, only devices that support the Qi wireless standard are recommended.

Do not place foreign objects on the charging pad whilst in use, this may damage both the charging pad and the mobile device.

Do not cover or obstruct the wireless charge pad's vents, this may lead to overheating and cause damage to the device.