

# EFM

## BERGEN SPEAKER USER MANUAL



### Introduction:

Thank you for choosing the EFM® BERGEN BLUETOOTH SPEAKER!

You can use this product with any Bluetooth compatible device to stream music and enjoy handsfree calling. In order to get the best results when using the speaker, please read this manual first.

### Features:

- Volume and song control directly on speaker unit
- Stunning sound clarity
- Ultra-portable design
- Great for parties, indoor and outdoor
- Allows you to make and answer phone calls

### Specification:

Loudspeaker: 4Ω 3W  
SNR: 80dB  
Playtime: Up to 6hrs

Built-in Power: Li-ion 600mAh  
Charging: 5V, 500mAh  
Wireless Working Frequency: 2.4Ghz  
Wireless Transmission Distance: Up to 10m  
Dimensions: 78(D) x 37(H)mm  
Weight: 132g  
Speaker Dimension: 40mm

### Package Contents:



1. Bluetooth Speaker



2. AUX Cable



4. User manual



3. USB Charging cable

### Important Safety Precautions:

To ensure the safe use of your EFM BERGEN BLUETOOTH SPEAKER, please follow these precautions:

1. Keep the speaker and charging cable away from sources of excessive heat.
2. Do not operate the speaker with a damaged cable or after it has malfunctioned or been damaged in any way.
3. Do not attempt to disassemble the speaker unit.

### Charging your speaker:

1. Connect one end of the supplied USB charging cable to the charging port on your speaker.
2. Plug the other end of the USB charging cable into a suitable USB port on your computer or compatible charging device.
3. When charging a blue LED indicator light (located next to the Micro-USB port) will illuminate. The light will turn off when the unit is fully charged.

The speaker will take approx. 2 hours to charge completely.

### Pairing your speaker:

1. Ensure that the Bluetooth device you intend to pair is within 3 metres of the speaker unit and that the speaker unit is powered on.
2. Press and hold the "⏻" button to enter pairing mode which will be indicated when the blue LED light blinks continuously.
3. Go to your device's Bluetooth manager and select 'EFM BERGEN' from the menu.
4. Once successfully paired, the blue LED light will glow continuously.

### Hands-free Function:

1. Press "☎" to pick up a call.
2. Press and hold "☎" for 2 seconds to reject a call.
3. To hang up during a call press "☎"

### Button Functions:



**ON/OFF Switch**  
Press and hold "⏻" to power on  
Press and hold "⏻" again to power off

**M**

Press this button to activate the speakerphone function.  
When music is playing, press to play or pause a track.



**Next**  
Press to access the next track in a playlist.  
Press and hold to increase the volume.



**Volume Down**  
Press and hold to lower the volume or press to access the previous track.



**Answer Phone/Hang up/Play/Pause**  
Activates the speakerphone function or plays and pauses music tracks

### Troubleshooting

Problem	Solution
The speaker doesn't connect to device	Speaker needs to be connected/re-paired to device
A tone is heard every few seconds	Speaker needs to be charged
Bluetooth connection distance cannot reach to 10 metres	Avoid operating the Bluetooth speaker in areas of strong electromagnetic interference, such as near induction cookers, large power fans, motors etc. Ensure the speaker is fully charged and move it closer to the Bluetooth device
The speaker will not power on	Speaker needs to be charged
The speaker doesn't control track(s)/volume	Speaker needs to be in Bluetooth mode for full control
The speaker distorts at high volume	The devices' volume needs to be lowered