



POWER BANK 5000mAh WITH HIGH SPEED CHARGE




What's in EFM Power Bank Pack



EFM 5000mAh Power Bank




EFM 25cm Micro USB Charging Cable



Instructions and warranty

Specifications

Capacity	5000 mAh
Input	DC 5V/2A
Output	DC 5A/2.1A
Size	133x57x10mm
Weight	115g
Cycle Life	>500 times
Charge Time	2-4 Hour



Charging your Power Bank

1. Connect your EFM Power Bank to the micro USB input port.
2. Connect the USB charging cable to a USB power source such as your computer or charger to start charging.
3. Charge until 4 LED indicators are illuminated.
4. Disconnect the Power Bank from the power source.

Charging your devices

1. To charge your device, connect it via USB cable to the Power Bank.
2. The Power Bank will automatically recognise it is connected and will begin charging your device.
3. Ensure your device is on when charging to verify the connection is correct and charging commences.
4. When charging your device the white indicator lights on the Power Bank will illuminate. If the lights are not glowing it means the Power Bank has shut off.
5. Charge/discharge your Power Bank every 3 months when not in use for long periods of time to ensure the longevity of the Power Bank battery.

Checking the power level

1. Press the power button located on the left of your Power Bank.
2. If all four lights are on, it means the power level is between 75%-100%; if three lights are on, the power level is between 50%-70%; if two lights are on, the battery level is between 25%-50%; if only one light is on, the battery level is between 0-25%.
3. When only one light is on or if none of the lights are on, it is time to charge the Power Bank.

○○○○	●○○○	●●○○	●●●○	●●●●
4 lights off: Immediate charging required	1 light on: 0-25% power remaining	2 lights on: 25-50% power remaining	3 lights on: 50-75% power remaining	4 lights on: 75-100% power remaining

Safety Tips

1. Keep the Power Bank away from excessive heat, direct sunlight, humidity, water or other liquids.
 - Do not expose to heat or direct sun.
 - Do not open the battery casing under any circumstances.
 - Do not use this unit for anything other than its intended purpose.
 - Do not operate the Power Bank if it has been wet or damaged.
 - Do not operate the Power Bank with wet hands.
 - Do not cover the Power Bank or place on top of other electrical devices.
2. Keep ports free from dust, lint etc. that may interfere with connections.
3. Keep ports free from dust, lint etc. that may interfere with connections.
4. The Power Bank is not a toy - keep out of reach of children.



www.myefm.com

REPLACEMENT WARRANTY REGISTRATION INSTRUCTIONS

1. Register your product online at www.myefm.com/warranty (proof of purchase is required within 14 days of purchase. If not registered within 14 days of purchase, the 2 year replacement warranty is not applicable).
2. If you have any issues with our product during this time forward photos and a brief explanation for review to: info@myefm.com or via the contact us page on our website, www.myefm.com
3. Once reviewed and if approved, your free replacement product* will be sent to you free of charge anywhere within Australia.

*Please Note: Warranty covers EFM product not the device. The 2 Year free replacement warranty is limited to 1 replacement per verified proof of purchase registration.

REPLACEMENT WARRANTY DETAILS

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure (defective goods).

EFM will repair or replace such defective goods for up to 2 years from the date of purchase. This warranty is against defects in the goods purchased and does not cover damage caused by the

incorrect use or installation of the goods, or by modifications, or by accident. To claim under the warranty you need to return the product to the place of purchase (at your expense) with a valid receipt or other proof of purchase. If you are not able to return the product to the place of purchase you can contact:

EFM Service Department
61 Belmont Avenue, Belmont WA 6104
P: 1300 069 336 (1300 0 MYEFM)
E: info@myefm.com

This warranty is in addition to other rights and remedies of the consumer under Australian Consumer Law for Consumer Electronic Devices and Home Entertainment Products.