

134mm

70mm



EFM® FLUX 4-IN-1 WIRELESS CHARGING DOCK

PACK CONTENTS

1. EFM® FLUX 4-IN-1 CHARGING DOCK
2. 42W ULTRA FAST WALL CHARGER WITH ENCAPSULATED 1.5M TYPE-C CABLE
3. INSTRUCTIONS AND WARRANTY

IMPORTANT INFORMATION

- Please read the instruction manual before using this product.
- Do not modify, repair or dismantle the Charging Dock. Doing so may result in fire, electrical shocks, or a complete breakdown of the product, all of which are not covered under warranty.
- Do not use any diluent or volatile liquids to clean the product surface.
- Do not use the product in a hazardous location.
- The product should be kept in a dry and ventilated environment, do not store in an area of high humidity and/or temperature.
- Do not use unsupported devices on the wireless charge pads, only devices that support the Qi wireless standard are recommended.
- Do not place foreign objects on the charge pad whilst in use. This may damage both the charging dock and the device.

USING THE 4-IN-1 CHARGING DOCK

- The EFM® FLUX 4-in-1 Charging Dock can charge up to four devices at once. Each charging option is designed to provide optimal charging outputs:
- MagSafe compatible Charge Pad: Up to 15W
Apple Watch Compatible Charge Pad: 3W
Base Wireless Charge Pad: Up to 15W
USB-A Output: Up to 10W
- Connect the ultra-fast 42W wall charger included in this pack to a power socket.
 - Connect the type-C connector on the power supply to the input port as indicated on the back of the charging dock.
 - Before using any of the wireless charge pads, ensure all surfaces are clear of dust and foreign objects.
 - Place your Qi-Supported/MagSafe compatible mobile device on the desired charge pad*.
 - To charge a device via wired output, use an appropriate cable for your device and connect it to the USB-A output port on the charging dock.

NOTE: Only use the 42W power supply included in this pack to ensure optimal charging speeds when multiple devices are being charged at the same time.

***NOTE:** The proper placement of your mobile device onto the charge pad will depend entirely upon the location of the wireless charging coil within your mobile device. Mobile devices that are compatible with MagSafe will magnetically align with the charging coil to deliver fast and convenient charging.

WIRELESSLY CHARGING MOBILE DEVICES WITH CASES:

Wireless charging is designed to work on cases up to 3mm in depth. EFM® cannot guarantee that your device will charge if you have attached a case thicker than 3mm on to your mobile device. Please ensure that you remove any cases or covers before placing your mobile device on the wireless charge pad as they may reduce the charging efficiency. For optimal charging efficiency, secure attachment and to ensure accurate magnetic alignment, EFM® recommends using a MagSafe or compatible with MagSafe case, when using the Magsafe compatible charge pad.


LED INDICATOR

The LED on the front of the charging dock is designed to indicate charging on the base wireless charge pad.

The colour functions are as follows:

- Red – The dock has power but no devices are charging on the base wireless charge pad.
- Green – A devices is charging via the base wireless charge pad.

NOTE: The LED indicator will only change colour when a devices is being charged via the base wireless charge pad.



EFM® 2 YEAR REPLACEMENT WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. EFM® will happily repair or replace defective goods for up to 2 years from the date of purchase. This warranty is against defects in the EFM® goods purchased and does not cover damage caused by the incorrect use or installation of the goods, or by modifications, or by accident. To claim under the warranty, you need to return the faulty product to the place of purchase (at your expense) with a valid proof of purchase. . If you are not able to return the product to the place of purchase, please fill out a Warranty Claim Form on myefm.com/warranty-support and follow the prompts.

For any inquiries, please contact:
EFM® Customer Service Department
PO BOX 684, Belmont WA 6104
P: 1300 069 336 (1300 0 MYEFM)
E: info@myefm.com

Important:
The 2 Year Manufacturer's Warranty covers EFM® product and not your device. For more information visit myefm.com
This warranty is in addition to other rights and remedies of the consumer under Australian Consumer Law for Consumer Electronic Devices and Home Entertainment Products.