

EFM
MEMPHIS SPEAKER USER MANUAL



Introduction:

Thank you for choosing the EFM MEMPHIS BLUETOOTH® SPEAKER!

You can use this product with any Bluetooth compatible device to stream music and enjoy hands-free calling. In order to get the best results when using the speaker, please read this manual first.

| | |
|-------------------------------------|--|
| Specification: | Distortion: ≤1% |
| Bluetooth Version: 4.2+EDR | S/N: ≥ 75dB |
| DC INPUT: DC 5V 1.2A | Output Power: 24W |
| Battery Capacity: 7.4V/2200mAh | Dimensions: 263mm(L) x 148.3mm(W) x 152.4mm(H) |
| Battery Play Time: 6-10 Hours @ 75% | Weight: 2.039Kg |
| Battery Charging Time: 4.5-5h | |
| Output Power: 40.12W*2 | |
| Frequency Response: 120Hz-20kHz | |
| Driver: 3"x2 | |
| RMS: 10W*2(THD+10%) | |

Package contents:



- 1x Memphis Speaker
- 1x 3.5mm Audio Cable
- 1x Micro USB Cable
- 1x User Manual

Important Safety Precautions:

To ensure the safe use of your EFM MEMPHIS BLUETOOTH® SPEAKER, please follow these precautions:

- Keep the speaker and charging cable away from sources of excessive heat.
- Do not operate the speaker with a damaged cable or after it has malfunctioned or been damaged in any way.
- Do not attempt to disassemble the speaker unit.

Speaker Functions:



LED Indicator Modes:

Charging Mode: Red LED on
Fully Charged: Red LED off
Bluetooth Pairing Mode: Blue LED flashes quickly
Bluetooth Connected: Blue LED on
Playing: Blue LED flashes slowly

Charging your speaker:

- Before using the speaker for the first time charge it for at least 12 hours. To charge your speaker;
- Plug the Micro USB Cable into the port of the speaker.
 - The red LED turns on to indicate that the unit is charging.
 - Once fully charged, the red LED turns off.

Pairing your speaker:

- Place the speaker within 10m of the Bluetooth-enabled device.
- Slide the ON/OFF button to ON. The LED indicator light will flash blue to indicate Bluetooth pairing mode has been entered.

- Activate the Bluetooth function on your device. Please refer to the manufacturer's instructions if you are unsure how to activate this function.
- In your device's Bluetooth manager and select 'EFM MEMPHIS' from the menu. If required, enter the password '0000' to confirm & finalise pairing.
- To disconnect, select 'EFM MEMPHIS' from the menu in your device's Bluetooth manager and deselect it.

The speaker will automatically reconnect to devices that support automatic reconnection.

TWS Function (Connect Two):

You can pair 2 EFM Memphis Speakers together to create a surround sound effect. To do this;

- Connect the first speaker to your device via Bluetooth®
- Press the mode button for 3 seconds until "TWS Pairing" sounds and the LED indicator light starts to flash blue
- Turn on the second speaker and press the mode button for 3 seconds until a tone sounds and the LED indicator light starts to flash blue
- TWS paired will confirm the connection and the LED indicator light will show solid blue.

To Disconnect Paired Speakers:

- Press the mode button for 3 seconds until "TWS disconnected" sound.



REPLACEMENT WARRANTY REGISTRATION

Register your EFM product, including your proof of purchase (receipt) by completing the form at myefm.com/register within 14 days of purchase.

If in the future you have any issues with your product, complete the warranty claim form at myefm.com/warrantyclaim.

Once reviewed, and if approved, your free replacement product will be sent to you, free of charge, anywhere within Australia. Please allow up to 10 days for replacement delivery.

Product not registered within 14 days of purchase with a relevant proof of purchase document will not be eligible under the EFM replacement warranty program. This program covers EFM products only, not devices and/or device parts.

REPLACEMENT WARRANTY DETAILS

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure (defective goods).

EFM will repair or replace such defective goods for up to 2 years from the date of purchase. This warranty is against defects in the goods purchased and does not cover damage caused by the incorrect use or installation of the goods, or by modifications, or by accident. To claim under the warranty you need to return the product to the place of purchase (at your expense) with a valid receipt or other proof of purchase. If you are not able to return the product to the place of purchase you can contact:

EFM Service Department
61 Belmont Avenue, Belmont WA 6104
P: 1300 069 336 (1300 0 MYEFM)
E: info@myefm.com

This warranty is in addition to other rights and remedies of the consumer under Australian Consumer Law for Consumer Electronic Devices and Home Entertainment Products.