

EFM FLUX 15W WIRELESS CHARGE PAD USER'S MANUAL





WARRANTY DETAILS:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

EFM® will happily repair or replace defective goods for up to 5 years from the date of purchase. This warranty is against defects in the EFM® goods purchased and does not cover damage caused by the incorrect use or installation of the goods, or by modifications, or by accident.

To claim under the warranty, you need to return the faulty EFM® product to the place of purchase (at your expense) with a valid proof of purchase. If you are not able to return the product to the place of purchase, please fill out a Warranty Claim Form on myefm.com/warranty-support and follow the prompts.

For any inquiries, please contact:

EFM Customer Service Department

PO BOX 684, Belmont WA 6104

P: 1300 069 336 (1300 0 MYEFM) E: info@myefm.com

Important: The 5 Year Manufacturer's Warranty covers EFM® product and not your device.

For more information visit myefm.com

This warranty is in addition to other rights and remedies of the consumer under Australian Consumer Law for Consumer Electronic Devices and Home Entertainment Products



EFM FLUX 15W WIRELESS CHARGE PAD USER'S MANUAL



PACK CONTENTS:

- 1 x EFM® FLUX 15W Wireless Charge Pad
- 1 x Warranty Details/Instruction Manual
- 1 x 20W Dual Port Wall Charger

TECHNICAL SPECIFICATIONS:

Parameter	Value
Input	5V 3A/9V 2.22A/ 12V 1.67A
Output	5W/10W/7.5W/15W
Dimensions	64mm x 8mm
Weight	52g
Operational Ambient Temperature Ranges	0°C to 40°C

CAUTION:

- Please read the instruction manual before using this product.
- Do not modify, repair or dismantle the wireless charge pad. Doing so may result in fire, electric shocks or a complete breakdown of the product all of which are not covered under warranty.
- Do not use any volatile liquids to clean the product surface.
- 4. Do not use the product in a hazardous location.
- The product should be kept in a dry and ventilated environment, do not store in an area of high humidity and/or high temperature.

USING THE WIRELESS CHARGE PAD:

- Connect the 20W Dual Port Wall Charger to a power socket.
- Connect the cable from the EFM® FLUX 15W
 Wireless Charge Pad into the Type-C port on the wall
 charger.
- 3. Ensure that the charge pad is positioned with the fabric surface facing up.
- Place your Qi-Supported/MagSafe compatible mobile device on the charge pad*.
- 5. Check that the charge pad's LED status indicator lights up on placement of your device.

*Please Note: The proper placement of your mobile device onto the charge pad will depend entirely upon the location of the wireless charging coil within your mobile device.

Mobile devices that are compatible with MagSafe will magnetically align with the charging coil to deliver fast and convenient charging.



MOBILE DEVICES WITH CASES:

Wireless charging is designed to work on cases up to 3mm in depth. EFM® cannot guarantee that your device will charge if you have attached a case thicker than 3mm on to your mobile device.

Please ensure that you remove any cases or covers before placing your mobile device on the wireless charge pad as they may reduce the charging efficiency.

For optimal charging efficiency and to ensure accurate magnetic alignment, EFM® recommends using a MagSafe or compatible with MagSafe case.

WARNING:

Do not use unsupported devices on the wireless charge pad, only devices that support the Qi wireless standard are recommended.

Do not place foreign objects on the charging pad whilst in use. This may damage both the charging pad or prevent charging mobile device functions.