

FRONT



GETTING STARTED

To ensure that EFM Impact Flex and Samsung Galaxy S10 and S10+ work seamlessly, please follow the steps below:

1. Install the EFM Impact Flex Screen Armour on the S10/ S10+ device screen. Please find installation instructions overleaf. (Note: It is important to ensure the impact flex screen armour is installed before completing the 'Fingerprint Registration Process').
2. Before you begin your Fingerprint Registration Process go to Settings > Display > Enable Touch Sensitivity. This allows the Ultrasonic Sensor to read your fingerprint more accurately to unlock the device.
3. Once Touch Sensitivity is enabled, complete the 'Fingerprint Registration Process' on the device by going to Settings > Biometrics and Security > Fingerprints, then follow the prompts.

EFM Impact Flex products will work flawlessly with the Fingerprint Under Display feature found in S10 and S10+ devices if the process above is applied.

BACK



REPLACEMENT WARRANTY REGISTRATION INSTRUCTIONS

1. Register your product online at www.myefm.com/register (proof of purchase is required within 14 days of purchase. If not registered within 14 days of purchase, the 2 year replacement warranty is not applicable).
2. If you have any issues with our product during this time, forward photos and a brief explanation for review to: info@myefm.com or via the 'contact us' page on our website, www.myefm.com
3. Once reviewed, and if approved, your free replacement product will be sent to you, free of charge, anywhere within Australia.

REPLACEMENT WARRANTY DETAILS

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure (defective goods).


EFM will repair or replace such defective goods for up to 2 years from the date of purchase. This warranty is against defects in the goods purchased and does not cover damage caused by the incorrect use or installation of the goods, or by modifications, or by accident. To claim under the warranty you need to return the product to the place of purchase (at your expense) with a valid receipt or other proof of purchase. If you are not able to return the product to the place of purchase you can contact:

EFM Service Department
61 Belmont Avenue, Belmont WA 6104
P: 1300 069 336 (1300 0 MYEFM)
E: info@myefm.com

This warranty is in addition to other rights and remedies of the consumer under Australian Consumer Law for Consumer Electronic Devices and Home Entertainment Products.

HOW TO INSTALL

1. Remove the top section of the applicator tool labelled 'full body', insert the thicker bottom half plug into the device charge port until you hear a click sound.
2. Place the Impact Flex material onto the bottom half plug, lining it up with the 2 holes, and placing the 'full body' tool top section on the top to secure the screen armour and align it to the phone.
3. Holding the Impact Flex up, remove the bottom protective film, then align the Impact Flex camera cut out with camera on the device for optimal positioning.
4. Handle the screen armour using the tab and keep it straight to align it with the phone.
5. Moving in an upward direction from the bottom where the applicator tool is located, gently but firmly use the full width of the supplied paddle to smooth the Impact Flex down onto the device.
6. Once all screen armour is secured onto the device remove the final protective film alignment tabs and applicator to complete installation.



IMPORTANT NOTICE

For best results the screen must be completely free of all dirt, marks and particles prior to the application of the Screen Armour. Failure to do this may prevent the Screen Armour from adhering properly, resulting in a poor fit.

The cleaning wipe provided is highly flammable. Keep away from open flame and hands thoroughly after use.

ATTENTION

This warranty covers EFM products only, not the device, or the device's screen. The 2 year free warranty is limited to 1 replacement per proof of purchase registration.

To prolong the life of your device screen, we recommend that you use a protective case with a stadium or raised edge with your Screen Armour for 360° protection. If you chose not to use a case on your device, both your screen and Screen Armour may be prone to damage.